



GENERAL DESCRIPTION

Junckers PreLak is a fast drying, water-based primer for use on wooden floors in commercial, residential or sports areas.

The product is very suitable for priming of floors in wood species sensitive to changes in humidity.

Protective coats with one of Junckers water based floor lacquers have to be applied after priming.

PRODUCT DESCRIPTION

Product: Water-based acrylic primer.

Package sizes: 5 litre and 10 litre.

Appearance: Creamy/milky. Dries up to a clear film.

TECHNICAL DATA

Coverage: 8 m² per litre.

Before application: Stir or shake the lacquer well before use.

Application tools: Short hair roller.
Don't apply by pouring out the lacquer directly on the floor.

Substrate temperature: Minimum 15° C.

Dilution: Delivered ready for use. Dilution is not recommended.

Drying time: Approx. 1-2 hours at 20° C and 50 % RH.

RH:
Water-based products have a certain gluing effect and are therefore only recommended to be used in rooms with a stable humidity. The difference between highest and lowest RH must not fluctuate more than 30 % during the year.

Cleaning of tools: Soap and water immediately after use. Junckers Thinner 006 after drying.

Storage: Lasts for 1 year if unopened and stored at 20° C. Not to be exposed to temperatures below 0° C.

SYSTEM RECOMMENDATIONS

High traffic areas:

1 coat Junckers PreLak 8 m²/litre + 2 coats Junckers HP Commercial 10 m²/litre
or

1 coat Junckers PreLak 8 m²/litre. + 2 coats Junckers STRONG 10 m²/litre.

Low traffic areas:

1 coat Junckers PreLak 8 m²/litre + 2 coats Junckers ProFinsh 10 m²/litre

Sport areas:

1 coat Junckers PreLak 8 m²/litre + 2 coats Junckers HP SPORT 10-12 m²/litre

DIRECTION FOR USE

Untreated/sanded floors:

The surface should be clean, dry and free from dust, wax, grease, polish etc.. Machine sand the surface to remove dirt and irregularities. Vacuum thoroughly and wipe off with a well wrung cloth and clean water.

The final sanding, before applying Junckers PreLak should be carried out by using sandpaper grit 120-150.

Apply one coat of Junckers PreLak using a clean, shorthaired roller or applicator. Do not apply by spraying.

When the primer is dry, sand with sandpaper grit 150-180 or a black screening pad. Then finish the floor with one of Junckers recommended floor lacquers.

Previously sealed floors:

Machine sand before applying Junckers PreLak. Use grit 24-36 to strip previous coats.

Then remove abrasion marks with grit 60-80. Finally, use grit 120-150 to obtain a completely smooth surface.

Vacuum sanding dust and wipe off with a well wrung cloth and clean water. Prime the floor as described under "Untreated/ sanded floors".

IMPORTANT

Before use of the product, read the label on the container carefully and observe the advised precautionary safety measures.

FURTHER INFORMATION

Products:

F 4.2 - Junckers ProFinish

F 5.1 - Junckers STRONG

F 6.5 - Junckers Thinner 006

F 8.2 - Junckers HP SPORT

F 8.5 - Junckers HP Commercial