



General Description

Junckers ProFinish is a water-based low odour lacquer for easy and convenient use in residential/domestic areas.

Junckers ProFinish is used on both previously finished as well as on new or sanded old floors.

Junckers ProFinish is also suitable for lacquering all kinds of indoor woodwork.

Technical Data

Product:	Water-based acrylic/polyurethane lacquer.
Package sizes:	Ultramatt, Matt, Silk Matt or Gloss: 5 litre. Ultramatt or Silk Matt: 10 litre.
Appearance:	Creamy/milky in the container. Colourless film when dry.
Gloss:	Ultramatt, Matt, Silk Matt or Gloss.
Coverage:	10 m ² per litre.
Before application:	Stir or shake carefully before use.
Application tools:	Brush, short hair mohair roller, air/airless spray.
Substrate temperature:	Minimum 10°C.
Dilution:	Junckers ProFinish is delivered ready for use. Dilution is not recommended.
Drying time:	Approx. 4 hours at 20°C and 50 % RH. Important! Apply only 2 coats per day. Maximum hardness is achieved after 72 hours.
Cleaning of tools:	Rinse tools in soapy water before the lacquer dries. Dried material can be removed with Junckers Thinner 006 .
Storage:	Lasts for 2 years if unopened and stored at 20°C. Not to be exposed to temperatures below 0°C.

System Recommendations

High traffic areas: Not recommended.

Domestic and light commercial traffic areas: 1 coat **Junckers PreLak** 8 m²/ltr
+ 2 coats **Junckers ProFinish** 10 m²/ltr.

Directions for Use

Untreated/Sanded Floors:

Ensure that the surface is absolutely clean, dry and free from all dust, wax, grease, polish and soap residues etc. Sand the surface to remove dirt and irregularities. Vacuum thoroughly.

Apply **Junckers PreLak** and Leave to dry. Sand with 150-180 grit sandpaper along the fibres of the wood.

Vacuum sanding dust and wipe with a well wrung out cloth and clean water.

Apply a coat of **Junckers ProFinish**. Leave to dry overnight and then apply the last coat.

Previously Lacquered Floors:

Wash with **Junckers Sylva Neutralizer**. Sand thoroughly using grit 150-180. Vacuum sanding dust and wipe well with a well wrung out cloth and clean water.

Trial applications should be tried on a couple of spots, 2 coats at 4 hours interval. After drying for 24 hours check the spots for adhesion by scraping with the edge of a coin. If the adhesion is good and the surface is acceptable, the floor can be lacquered.

If not satisfactory, proceed as under "**Wax/Polish Treated floors**".

Wax/Polish Treated Floors:

Machine sand by first using grit 24-36 to strip old coats. Then remove abrasion marks using grit 60-80. Finally, use grit 120-150 to obtain a completely smooth surface.

Vacuum thoroughly. Treat the floor as described under "**Untreated/ Sanded floors**".

Important!

Before use of the product, read the label on the container carefully and observe the advised precautionary safety measures.

Important!

Water-based products have a certain gluing effect and are therefore recommended to be used in rooms with a stable humidity.

Important!

Don't apply by pouring out the lacquer. Apply using recommended tools.

Important!

Stir well before use.

Further information

Products:

F 5.3 - **Junckers PreLak**

F 6.5 - **Junckers Thinner 006**

F 10.3 - **Junckers Sylva Neutralizer**